

MC-9 PARTS MANUAL**SECTION****8B****6V-92TA (C) ENGINE**

Description	Page Number
Accessory Drive - Type 382	8B.1.74
Air Box Drain - Types 161 & 167	8B.1.12
Air Compressor Drive - Type 230	8B.1.73
Air Inlet Housing - Type 750	8B.3.30
Balance Weight Cover - Type 49	8B.1.72
Blower - Types 477 & 484	8B.3.40
Blower Drive Shaft - Types 47 & 54	8B.3.40
Camshaft & Gear Train (California) Types 378 & 535	8B.1.70
Camshaft & Gear Train (Federal) Types 494 & 519	8B.1.70
Connecting Rod & Piston - Types 274 & 376	8B.1.60
Crankshaft - Type 64	8B.1.30
Crankshaft Pulley - Type 53	8B.1.31
Cylinder Block - Type 226	8B.1.10
Cylinder Head - Type 136	8B.1.20
Dipstick - Type 991	8B.4.60
Engine & Transmission Combinations	i
Engine Lifter Bracket - Type 32	8B.1.22
Exhaust Manifold - Type 470	8B.6.10
Fast Idle Air Cylinder - Governor Assembly	8B.2.76
Flex Plate W/Auto Transmission - Type 847	8B.1.53
Flywheel W/Std Transmission - Type 831	8B.1.53
Flywheel Housing (Stl) Type 580	8B.1.50
Flywheel Housing (Alum) Types 679 & 744	8B.1.50
Fuel Filter	8B.2.30
Fuel Injectors - Type 237	8B.2.10
Fuel Lines - Type 1407	8B.2.40
Fuel Manifold Connections - Type 52	8B.2.40
Fuel Pump Assembly (Std) Type 174	8B.2.20
Fuel Strainer	8B.2.31
Governor Assembly (Ltd Spd - Dbl Wt) Types 1658, 1773, 2030, & 2031	8B.2.70
Governor Assembly (Two Speed) Types 1599, 2015, & 2044	8B.2.70
Hydraulic Pump Drive - Type 175	8B.12.50
Injector Controls - Types 296, 298, 329, & 330	8B.2.90
Model Description Chart	iii
Oil Cooler W/Auto Transmission - Type 1058	8B.4.40
Oil Cooler W/Auto Transmission - Type 1152	8B.4.42
Oil Cooler W/Std Transmission - Types 949/1062	8B.4.44
Oil Cooler W/Std Transmission - Type 1166	8B.4.46
Oil Distribution System - Type 477	8B.4.11
Oil Filler - Type 125	8B.4.50
Oil Filter - Types 370 & 457	8B.4.20
Oil Pan - Type 224	8B.4.70
Oil Pressure Regulator - Type 28	8B.4.12

MC-9 PARTS MANUAL

Description	Page Number
Oil Pump - Types 114 & 192	8B.4.10
Rocker Covers - Type 337	8B.1.82
Standard & Standard Option Equipment	iv
Tachometer Drive - Type 504	8B.7.40
Thermostat - Type 266	8B.5.20
Turbocharger Aftercooler - Types 839 & 868	8B.3.50
Turbocharger Assembly - Type 839	8B.3.52
Turbocharger Assembly - Type 868	8B.3.53
Valve Injector Operating Mechanism - Type 243	8B.1.80
Ventilating System (Rocker Cover) Type 727	8B.4.80
Ventilating System (Engine) Type 728	8B.4.80
Water By-Pass Tube - Type 438	8B.5.20
Water Pump - Types 176 & 238	8B.5.10

RELATED PARTS

Alarmstat	8B.2802
Belts	8B.0401
Clamps (Hose) Constant Torque	8B.2002
Clutch Switch W/Jake Brake	8B.3206
Crankcase Ventilation W/O Jake Brake	8B.1001
Engine Assembly	8B.0101
Engine Cradle Assembly & Mounting Parts	8B.1801
Engine Oil Filter & Mounting Bracket W/Auto Trans	8B.1002
Exhaust System - Stainless Steel	8B.2002
Fast Idle Buffer Switch W/Jake Brake	8B.3206
Fuel Filter - Spin-on	8B.3301
Gauges & Sending Units	8B.2801
Governor Air Valve & Cylinders	8B.2203
Governor Assembly (Type 2141) Two Speed	8B.2201
Jacobs Engine Brake	8B.3201
KBI Pressurized Ether Start	8B.2206
Muffler	8B.2001
Oil Cooler Gasket - Engine	8B.1001
Oil Fill Tube Assembly W/Jake Brake	8B.3204
Oil Fill Tube Assembly W/O Jake Brake	8B.1001
Pulleys	8B.0401
Rocker Covers W/Jake Brake	8B.3204
Solenoid Valve - Engine Stop & Fast Idle	8B.2205
Transmission Covers	8B.2101
Underpans - Engine/Transmission	8B.2102